LINKSYS®

Quick Installation

For Windows XP *ONLY*

This Quick Installation is meant to help you install the product quickly and easily. For detailed instructions on installation, configuration, and further setup options, please consult the User Guide.

Instant Wireless® Series

WMP11

Wireless-B PCI Adapter

Package Contents

- Wireless-B PCI Adapter
- External Antenna
- Setup Wizard CD-ROM with User Guide
- Quick Installation and Registration Card

1 Installing the PCI Adapter

Important for Windows XP users: You must install the Adapter's hardware before installing the software.

A. Remove any CDs or disks from their drives, and turn off your desktop PC.

B. Open your PC's case, and locate an available PCI slot on the motherboard. Check with your computer manufacturer for instructions.

C. Slide the Adapter into the PCI slot. Make sure that all of its pins are touching the slot's contacts. You may have to apply a bit of pressure to slide the Adapter all the way in.

D. After the Adapter is set firmly in place, secure its fastening tab to your PC's chassis with a mounting screw. Then close your PC's case.

E. Attach the external antenna to the Adapter's antenna port.

F. Power on your desktop PC.

Now that the Adapter is installed, proceed to "Step 2: Driver Installation and Configuration for Windows XP."

2 Driver Installation and Configuration for Windows XP

A. Windows XP will automatically detect the Adapter. Insert the Setup Wizard CD-ROM into your CD-ROM drive. Click the radio button next to **Install the software automatically (Recommended)**. Then click the **Next** button.

Found New Hardware Wizard
Welcome to the Found New Hardware Wizard
This wizard helps you install software for:
Ethernet Controller
If your hardware came with an installation CD or floppy disk, insert it now.
What do you want the wizard to do?
Install the software automatically (Recommended)
Install from a list or specific location (Advanced)
Click Next to continue.
< Back
Next >
Cancel
A

B. Windows will notify you that the driver has not passed Windows Logo testing Click the **Continue Anyway** button.

C. After Windows has finished installing the driver, click the **Finish** button.

Continued on back

D. Windows XP has a built-in configuration tool. After installing the Adapter, the Windows XP Wireless Zero Configuration icon will appear in your computer's system tray. Double-click the icon.

Wireless Network Connection
One or more wireless networks are available.
To see a list of available networks, click here.
4:19 PM
D

Note: Steps E and F are the instructions and screenshots for Windows XP with Service Pack 1 installed. If you have not installed Service Pack 1, select the network you want, and click the **Connect** button. If the network has WEP encryption enabled, enter the WEP key in the *Network key* field, and then click the **Connect** button.

E. The screen that appears will show any available wireless network. Select the network you want.

If this network has WEP encryption enabled, go to Step F.

If this network does not have WEP encryption enabled, then the screen in Figure E will appear. Make sure the box next to *Allow me to connect to the selected wireless network, even though it is not secure* is checked. Then click **Connect**, and go to Step G.

Wireless Network Connection 4
The following wireless network(s) are available. To access a wireless network, select it from the list, and then click Connect.
Available wireless networks:
linksys
This wireless network is not secure. Because a network key (WEP) is not used for authentication or for data encryption, data sent over this network might be subject to unauthorized access.
Allow me to connect to the selected wireless network, even though it is not secure
If you are having difficulty connecting to a network, click Advanced.
Connect
Cancel
E

F. If WEP is enabled, the screen in Figure F will appear. Enter the WEP key of your wireless network in the *Network key* field, and re-enter it in the *Confirm network key* field. Then click **Connect**.

To find the WEP encryption key settings of the other wireless devices in your network, such as the WAP11 Wireless Access Point, you may use any device's web-based utility to check the WEP encryption screen for the correct key entries. If you are using other manufacturers' access points, refer to their documentation for more information about WEP encryption.

Wireless Network Connection 4
The following wireless network(s) are available. To access a wireless network, select it from the list, and then click Connect.
Available wireless networks:
linksys
This wireless network requires the use of a network key (WEP). To access this network, type the key, then click Connect.
Network key:
Confirm network key:
Enable IEEE 802.1x authentication for this network
If you are having difficulty connecting to a network, click Advanced.
Connect
Cancel
F

Important: Windows XP Wireless Zero Configuration does not support the use of a passphrase. Enter the exact WEP key used by your access point.

G. The screen in Figure G will appear if your connection is active.



For more information about wireless networking on a Windows XP computer, enter the keyword **wireless** in the Windows XP search engine.

Windows XP users: Congratulations!
The installation of the Wireless-B PCI Adapter is complete.

For additional information or troubleshooting help, refer to the User Guide on the Setup CD-ROM. You can also call or email for further support.

24-hour Technical Support	***800-326-7114 (toll-free from US or Canada)***
E-mail Support	***support@linksys.com***
Website	***http://www.linksys.com or http://support.linksys.com***
RMA (Return Merchandise Authorization)	***http://www.linksys.com/support***
FTP Site	***ftp://ftp.linksys.com***
Sales Information	***800-546-5797 (800-LINKSYS)***

WMP11_v4-QI_XP-30602A KL